



FUZE® ProLine Feeders Control Pans and Feed Line System

Repair Parts List

Pan and Grill examples

Val-co® provides 2 FUZE® feeder pan types, the FUZE® ProLine RLS shallow pan assemblies and FUZE® ProLine RS standard pan assemblies.



RLS = SHALLOW PAN ASSEMBLY



RS - STANDARD PAN ASSEMBLY



13" - 13 spoke GRILL




14" - 14 spoke GRILL



14" - 5 spoke GRILL

Exploded views and Part Lists are on the following pages.


FUZE® ProLine Feeder Exploded View




FUZE® ProLine Feeder Parts List

PART #	DESCRIPTION	QTY
FE1500RS, FE1500RLS, FE1600RS, FE1600RLS, FE1800RS, FE1800RLS - Shared Parts		
FE1530	FUZE® FEEDER TOWER	1
FE1550	FUZE® FEEDER TOWER CAP	1
FE1500 RS (STANDARD PAN) and FE1500RLS (SHALLOW PAN) parts specific to model		
FE1510S	13" FUZE® SLOTTED STANDARD PAN W/ HINGE & LOCK	1
FE1520R	13" FUZE® Pro GRILL SHALLOW PAN - 13 SPOKE W/ HINGE & LOCK	1
FE1540	FUZE® ADJ COLLAR - STANDARD PAN	1
FE1540S	FUZE® ADJ COLLAR - SHALLOW PAN	1
FE1600RS (STANDARD PAN) and FE1600RLS (SHALLOW PAN) parts specific to model		
FE1610S	14" FUZE® SLOTTED STANDARD PAN W/ HINGE & LOCK	1
FE1620R	14" FUZE® Pro GRILL SHALLOW PAN - 14 SPOKE W/ HINGE & LOCK	1
FE1540	FUZE® ADJ COLLAR - STANDARD PAN	1
FE1540S	FUZE® ADJ COLLAR - SHALLOW PAN	1
FE1800RS (STANDARD PAN) and FE1800RLS (SHALLOW PAN) parts specific to model		
FE1610S	14" FUZE® SLOTTED STANDARD PAN W/ HINGE & LOCK	1
FE1820R	14" FUZE® Pro GRILL SHALLOW PAN- 5 SPOKE W/ HINGE & LOCK	1
FE1540	FUZE® ADJ COLLAR - STANDARD PAN	1
FE1540S	FUZE® ADJ COLLAR - SHALLOW PAN	1

FUZE® ProLine (One Piece) Exploded View



RS-S = STANDARD PAN ASSEMBLY




RLS-S= SHALLOW PAN ASSEMBLY

FUZE® ProLine Feeder (One Piece) Parts List

PART #	DESCRIPTION	QTY
FE1500RS-S, FE1500RLS-S, FE1600RS-S, FE1600RLS-S, FE1800RS-S, FE1800RLS-S - Shared Parts		
FE1533	FUZE® ONE PC TOWER	1
FE1540	FUZE® ADJ COLLAR-STANDARD PAN	1
FE1540S	FUZE® ADJ COLLAR-SHALLOW PAN	1
FE1500RS-S (STANDARD PAN) and FE1500RLS-S (SHALLOW PAN) parts specific to model		
FE1510S	13" FUZE® SLOTTED STANDARD PAN W/ HINGE & LOCK	1
FE1510LS	13" FUZE® SLOTTED SHALLOW PAN W/HINGE & LOCK	1
FE1520R	13" FUZE® Pro GRILL SHALLOW PAN - 13 SPOKE W/ HINGE & LOCK	1
FE1600RS-S (STANDARD PAN) and FE1600RLS-S (SHALLOW PAN) parts specific to model		
FE1610S	14" FUZE® SLOTTED STANDARD PAN W/ HINGE & LOCK	1
FE1610LS	14' FUZE® SLOTTED SHALLOW PAN W/HINGE & LOCK	1
FE1620R	14" FUZE® Pro GRILL SHALLOW PAN - 14 SPOKE W/ HINGE & LOCK	1
FE1800RS-S (STANDARD PAN) and FE1800RLS-S (SHALLOW PAN) parts specific to model		
FE1610S	14" FUZE® SLOTTED STANDARD PAN W/ HINGE & LOCK	1
FE1610LS	14" FUZE® SLOTTED SHALLOW PAN W/HINGE & LOCK	1
FE1820R	14" FUZE® Pro GRILL SHALLOW PAN- 5 SPOKE W/ HINGE & LOCK	1


Exploded Control Pan with Proximity Switch



Control Pan with Proximity Switch Parts List

PART #	DESCRIPTION	QTY
Interchangeable Parts		
450965	3/8" CABLE COVER	2
451008	1-3/4" SS TUBE CLAMP	3
455926	FUZE® PROX CONTROL TOWER	1
455928	7/8" HOSE CLAMP	1
750437	SENSOR, PROXIMITY, DOL26	1
820158	FUZE® NON-SWING BRACKET	2
820177	BRACKET, PROX SENSOR MTG	1
FE1550	FUZE® FEEDER TOWER CAP	1
(parts specific to) 455919		
FE1540	FUZE® ADJ COLLAR - STANDARD PAN	1
FE1610S	14" FUZE® SLOTTED STANDARD PAN W/ HINGE & LOCK	1
FE1620R	14" FUZE® Pro GRILL - 14 SPOKE W/ HINGE & LOCK	1
(parts specific to) 455920		
FE1540	FUZE® ADJ COLLAR - STANDARD PAN	1
FE1510S	13" FUZE® SLOTTED STANDARD PAN W/ HINGE & LOCK	1
FE1520R	13" FUZE® Pro GRILL - 13 SPOKE W/ HINGE & LOCK	1
(parts specific to) 455921		
FE1540S	FUZE® ADJ COLLAR - SHALLOW PAN	1
FE1510LS	13" FUZE® SLOTTED SHALLOW PAN W/HINGE & LOCK	1
FE1520R	13" FUZE® Pro GRILL - 13 SPOKE W/ HINGE & LOCK	1
(parts specific to) 455922		
FE1540S	FUZE® ADJ COLLAR - SHALLOW PAN	1
FE1610LS	14" FUZE® SLOTTED SHALLOW PAN W/ HINGE & LOCK	1
FE1620R	14" FUZE® Pro GRILL - 14 SPOKE W/ HINGE & LOCK	1
(parts specific to) 455923		
FE1540	FUZE® ADJ COLLAR - STANDARD PAN	1
FE1610S	14" FUZE® SLOTTED STANDARD PAN W/ HINGE & LOCK	1
FE1820R	14" FUZE® Pro GRILL - 5 SPOKE W/ HINGE & LOCK	1
(parts specific to) 455924		
FE1540S	FUZE® ADJ COLLAR - SHALLOW PAN	1
FE1610LS	14" FUZE® SLOTTED SHALLOW PAN W/ HINGE & LOCK	1
FE1820R	14" FUZE® Pro GRILL - 5 SPOKE W/ HINGE & LOCK	1

Exploded Control Pan with Mechanical Switch






Control Pan with Mechanical Switch Parts List

PART #	DESCRIPTION - CONTROL PANS	QTY
Interchangeable Components (all Mech. Switch models)		
450965	3/8" CABLE COVER	1
451008	1-3/4" SS TUBE CLAMP	2
820158	FUZE® NON-SWING BRACKET	1
820323	SWITCH, SPDT, 21A, 277VAC 1HP/125VAC, HP/250VAC	1
820319	TOWER, ADJ. SWITCH, FUZE® CONTROL PAN	1
820324	WIRING ASSY, FUZE® CNTL PAN, MECH SWITCH	1
FE1550	FUZE® FEEDER TOWER CAP	1
(parts specific to) 820327		
FE1510S	13" FUZE® SLOTTED STANDARD PAN W/HINGE & LOCK	1
FE1520R	13" FUZE® GRILL - 13 SPOKES W/ HINGE & LOCK	1
FE1540	FUZE® ADJ COLLAR - STANDARD PAN	1
(parts specific to) 820328		
FE1510LS	13" FUZE® SLOTTED SHALLOW PAN W/ HINGE & LOCK	1
FE1520R	13" FUZE® Pro GRILL - 13 SPOKE W/ HINGE & LOCK	1
FE1540S	FUZE® ADJ COLLAR - SHALLOW PAN	1
(parts specific to) 820329		
FE1610S	14" FUZE® SLOTTED STANDARD PAN W/HINGE & LOCK	1
FE1620R	14" FUZE® Pro GRILL - 14 SPOKE W/ HINGE & LOCK	1
FE1540	FUZE® ADJ COLLAR - STANDARD PAN	1
(parts specific to) 820330		
FE1610LS	14" FUZE® SLOTTED SHALLOW PAN W/ HINGE & LOCK	1
FE1620R	14" FUZE® Pro GRILL - 14 SPOKE W/ HINGE & LOCK	1
FE1540S	FUZE® ADJ COLLAR - SHALLOW PAN	1
(parts specific to) 820331		
FE1610S	14" FUZE® SLOTTED STANDARD PAN	1
FE1820R	14" FUZE® Pro GRILL - 5 SPOKE W/ HINGE & LOCK	1
FE1540	FUZE® ADJ COLLAR - STANDARD PAN	1
(parts specific to) 820332		
FE1610LS	14" FUZE® SLOTTED SHALLOW PAN W/ HINGE & LOCK	1
FE1820R	14" FUZE® Pro GRILL - 5 SPOKE W/ HINGE & LOCK	1
FE1540S	FUZE® ADJ COLLAR - SHALLOW PAN	1

Replacement Parts/Control Pan Mechanical Switch


820333
PADDLE ASSY, ADJ SWITCH
FUZE® CONTROL PAN

Tower is shown in low
opacity for orientation.
Tower parts are not
included with Paddle Assy





PART #	DESCRIPTION	QTY
REPLACEMENT PARTS (ordered as assemblies shown below)		
820323	SWITCH, SPDT, 21A, 277VAC, 1HP/125VAC, 2HP/250VAC	1
820324	WIRING ASSEMBLY, FUZE® CONTROL PAN, MECH SWITCH	1
820333	PADDLE ASSY, ADJ SWITCH FUZE® CONTROL PAN	1

Bird Attracting LED light for Control Pans (Universal)




PART #	DESCRIPTION	QTY
820022 BIRD ATTRACTING LIGHT		
451008	1-3/4" SS TUBE CLAMP	1
820165	LIGHT, LED, CONTROL PAN	1
820184	BRACKET, LED FEEDER LIGHT MTG	1
920808	ADAPTER, 1/2"NPTF X SKT, SCH40 NON-METALIC	1
920946	CABLE, 18/2 18AWG, 10A, 300V, BLK, PVC JACKET, .29 OD	3
980057	CONNECTOR, ELECT, FLAG, FEM, .187 X.020, 22-18, FULLY INSULATED	2
921155	CONDUIT SCHEDULE 40 1/2" x 2"	1
CN-004-001	ADAPTER, 1/2"NPTM X SKT, SCH40 NON-METALIC	1
HW-71-011	STRAIN RELIEF CABLE DOME 1/2	1
PMHC3/4	TRIDON HOSE CLAMP 3/4"	2

Best Start Chick Feeder (FE300, FE300CR)




PART #	DESCRIPTION	QTY
Interchangeable Parts		
FE310	SPOOL FOR BEST START CHICK FEEDER	1
FE320	DROP FOR BEST START CHICK FEEDER	1
FE300NUT	#8-32 SQUARE NUT, 11/32"WD X 1/8" THR SS	1
FE300SCR	#8-32 x 3/4 " PHILLIPS ROUND 188 SS	1
FE300TAPSCREW	NO.4 X 3/4"LONG PAN HD SHT METAL SCR SS	1
FE300 - BEST START CHICK FEEDER		
FE330	EXTENDER FOR BEST START CHICK FEEDER	1
FE340	CAP FOR EXT. FOR BEST START CHICK FEEDER	1
FE300CR - BEST START CHICK FEEDER W/CROWN SLEEVE		
FE350	HOOKEED EXTENDER FOR BEST START FEEDER (USE WITH FE360)	1
FE360	CROWN SPREADER FOR BEST START FEEDER (USE WITH FE350)	1

Best Start Chick Feeder II (820005, 820006)



PART #	DESCRIPTION	QTY
820005	BEST START II CHICK FEEDER	1
820006	BEST START II CHICK FEEDER - OPTIONAL STAND. EXTENSION	1
820009	BEST START II CHICK FEEDER -OPTIONAL 6" EXTENSION BOX OF 50	1
<i>All the above are shipped in quantities of 50 per box</i>		
HARDWARE and WASHER (Included)		
No Val-Co equivalent Part #	10-24 x 1" Hex Bolt	50
No Val-Co equivalent Part #	10-24 x 2-1/4" Hex Bolt	50
No Val-Co equivalent Part #	10-24 Nylock Nut	100
No Val-Co equivalent Part #	RUBBER WASHER	50

Direct Drive and Gearbox Exploded view and Parts List




PART #	DESCRIPTION	QTY
450287 MOTOR/GEARBOX ASSY – 543/657 RPM 1P		
735390	MTR,.50HP,115/230V,50/60HZ,1P 1425/1725RPM,56N,SF1.00,IN.B	1
450369	GEARBOX, 2.63:1 RATIO, 3/4 SH 56N DIE CAST AL	1
450366	1/2" PINION DIE CAST- COMPLETE	1
450391 MOTOR/GEARBOX ASSY – 359 RPM 3P		
735460	MTR,.50HP,190/380&208-230/460V 50&60HZ,3P,1425/1725RPM,56N	1
450365	GEARBOX, 4.81:1 RATIO, 3/4 SH 56N, DIE CAST AL	1
450366	1/2" PINION DIE CAST- COMPLETE	1
450393 MOTOR/GEARBOX ASSY – 441 RPM 1P		
735390	MTR,.50HP,115/230V,50/60HZ,1P 1425/1725RPM,56N,SF1.00,IN.B	1
450368	GEARBOX, 3.91:1 RATIO, 3/4 SH 56N, DIE CAST AL	1
450366	1/2" PINION DIE CAST- COMPLETE	1
450395/MOTOR/GEARBOX ASSY – 441 RPM 3P		
735460	MTR,.50HP,190/380&208-230/460V 50&60HZ,3P,1425/1725RPM,56Y	1
450368	GEARBOX, 3.91:1 RATIO, 3/4 SH 56N, DIE CAST AL	1
450366	1/2" PINION DIE CAST- COMPLETE	1
450397/MOTOR/GEARBOX ASSY – 226 RPM 1P		
735390	MTR,.50HP,115/230V,50/60HZ,1P 1425/1725RPM,56N,SF1.00,IN.B	1
450367	GEARBOX, 7.63:1 RATIO, 3/4 SH 56N, DIE CAST AL	1
450366	1/2" PINION DIE CAST- COMPLETE	1
451028/MOTOR/GEARBOX ASSY – 657 RPM 1P		
735392	MTR,1HP,115/208-230V,50/60HZ 1P,1725RPM,56Y,SF1.15,IN.B	1
450369	GEARBOX, 2.63:1 RATIO, 3/4 SH 56N, DIE CAST AL	1
730094	5/8" PINION (DIE CAST)	1
ADDITIONAL MOTOR MODELS AND INTERCHANGEABLE PARTS ON NEXT PAGE		

Direct Drive and Gearbox Exploded view and Parts List - continued


PART #	DESCRIPTION	QTY
451101/MOTOR/GEARBOX ASSY – 359 RPM 3P		
920451	MTR, 0.75HP, 380V, 60HZ, 3P 1720RPM, 56C, SF1.15, IN.F	1
730126	3-PHASE ADAPTER FACE PLATE	1
450365	GEARBOX, 4.81:1 RATIO, 3/4 SH 56N, DIE CAST AL	1
730094	5/8" PINION (DIE CAST)	1
451102/MOTOR/GEARBOX ASSY – 657 RPM 3P		
920451	MTR, 0.75HP, 380V, 60HZMPLTE, 3P 1720RPM, 56C, SF1.15, IN.F	1
730126	3-PHASE ADAPTER FACE PLATE	1
450369	GEARBOX, 2.63:1 RATIO, 3/4 SH 56N, DIE CAST AL	1
730094	5/8" PINION (DIE CAST)	1
460025/MOTOR/GEARBOX ASSY – 296/359 RPM 1P		
735390	MTR,.50HP,115/230V,50/60HZ,1P 1425/1725RPM,56N,SF1.00,IN.B	1
450365-PH	GEARBOX, 4.81:1 RATIO, 3/4 SH 56N, DIE CAST AL	1
450366	1/2" PINION DIE CAST- COMPLETE	1
Interchangeable Parts		
010252	WASHER, LOCK 5/16" MED SPLIT ZP	2
010647	5/16" X 1-1/4" HEX BOLT	2
012755	WASHER, FLAT, 3/4" SAE	1
450366	1/2" PINION DIE CAST- COMPLETE	1
450369	GEARBOX, 2.63:1 RATIO, 3/4 SH 56N, DIE CAST AL	1
450455	1/4-20 THREAD DRIVE BLOCK	1
450461	1/4-20 X 1-1/2" SOCKET HEAD SCREW	1
450696	.028 AUGER SHIM	1
730141	VENT PLUG	1

Drive End Control, 1PH, DPST Relay (455960)




PART #	DESCRIPTION	QTY
DRIVE END CONTROL, 1PH, DPST RELAY (455960)		
010645	5/16" X 1" HEX BOLT	4
012789	5/16-18 NYLOCK NUT	4
420473	1/2" CONDUIT NUT	2
450057	ANTI-ROOST GUARD WIRE	1
450484	GROUND BLOCK	1
451042	ANTI-ROOST INSULATOR BRACKET ASSEMBLY	1
455106	BROILER DRIVE UNIT TUBE JOINER	2
455911	TOP PLATE ASSEMBLY	1
455950	1 PH DRIVE END WELDMENT	1
455952	BOTTOM GUARD AND SUPPORT	1
690364	#6-19 X 3/8" PPHMS SCREW	8
730044	POWER RELAY, DPST 25A 240V	1
730452	ENCLOSURE 5" X 7" X 3"	1
730514	6-32 X 1/4" PPH TRS SCREW	3
730516	10-32 X 1/4" PPH TRS SCREW	1
730521	TERMINAL, SPADE, 16-14AWG, #6	8
730541	MOUNTING PLATE, CONTROL BOX	1
750030	STRAIGHT-THRU GROMMET	2
936053	#10 X 1/2" SHEET METAL SCREW	7
HW-71-204	O-RING, 11/16" ID, 13/16" OD	2

Drive End Control, 1PH or 3PH, No Relay (455965)




PART #	DESCRIPTION	QTY
DRIVE END CONTROL, 1PH OR 3 PH, NO RELAY (455965)		
010645	5/16" X 1" HEX BOLT	4
012725	#12 X 1/2" HEX HEAD SHEET METAL SCREW	4
012789	5/16-18 NYLOCK NUT	4
450057	ANTI-ROOST GUARD WIRE	1
450779	SQUARE ENCLOSURE, 3.7" X 3.7" X 3.19"	1
451042	ANTI-ROOST INSULATOR BRACKET ASSEMBLY	1
455106	BROILER DRIVE UNIT TUBE JOINER	2
455911	TOP PLATE ASSEMBLY	1
455952	BOTTOM GUARD AND SUPPORT	1
455953	3 PH DRIVE END WELDMENT	1
936053	#10 X 1/2" SHEET METAL SCREW	7

Single Boot Exploded (450810)




PART #	DESCRIPTION	QTY
450810 SINGLE BOOT		
450413	AGITATOR BALL	1
450813	1.75" SGL BOOT LINER	1
450814	1.75" BOOT SUPPORT RAIL	1
450819	BOOT HANGER	2
450822	BEARING RETAINER TUBE	1
450823	1.75" BOOT HOUSING ASSY	1
450991	1-3/4" BEARING CAP	1
450993	1.75" FLGHT ANCHOR ASSY	1
451040	FEEDER TUBE CLAMP	1
451042	ANTI-ROOST INSULATOR BRACKET ASSEMBLY	1
501441	NUT, HEX FLANGE 5/16"-18, ZP JS500	2

Double Boot Exploded (450800)



PART#	DESCRIPTION	QTY
450800 DOUBLE BOOT		
450413	AGITATOR BALL	2
450801	1.75" TWIN BOOT SUPPORT RAIL	1
450822	BEARING RETAINER TUBE	2
450991	1-3/4" BEARING CAP	2
450993	1.75" FLGHT ANCHOR ASSY	2
450998	1.75" TWIN BOOT LINER	2
451040	FEEDER TUBE CLAMP	2
451042	ANTI-ROOST INSULATOR BRACKET ASSEMBLY	2
455801	1.75" TWIN BOOT HSG ASSY	1
455803	TWIN BROILER BOOT HANGER	2
501441	NUT, HEX FLANGE 5/16"-18, ZP JS500	4

Hopper Exploded Drawing





Hopper Parts List

PART #	DESCRIPTION	QTY 451315	QTY 451320
451315 100 LB HOPPER / 451320 200 LB HOPPER			
451309	100 LB HOPPER PANEL	4	-
451300	200 LB HOPPER PANEL	-	4
450956	HOPPER CROSS BRACE	1	1
451301	HOPPER BOTTOM BRACE	2	2
451312	HARDWARE BAG, 100 LB HOPPER	1	-
451313	HARDWARE BAG, 200 LB HOPPER	-	1
010424	WASHER, FLAT, 1/4" X 9/16" ZP	2	2
010615	1/4-20 X 1/2" HEX HEAD BOLT ZP	33	37
010643	BOLT, HEX HEAD, 5/16-18 X 3/4" ZP	6	6
012789	5/16-18 NYLOCK NUT	6	6
450780	CABLE RETAINER	2	2
451016	SUPPORT, FEED HOPPER DROP TUBE	1	1
451316	CLEVIS PIN, 1/4" X 9/16" ZP	2	2
451317	COTTER PIN, 5/64" X 1.25" LG ZP	2	2
690003	NUT, KEP 1/4-20 ZP	35	39
690340	SCREW, 1/4-20 X 1/2 SHCS ZP	1	1
735431	4" SS DOWNSPOUT CLAMP	2	2

450804 Cover for 100 lb. & 200 lb. available

451022 Extension for 200 lb. hopper available to increase capacity


Hopper Level Switch Control Exploded view



Hopper Level Switch Control Parts List

PART #	DESCRIPTION	QTY
720097 HOPPER LEVEL SWITCH CONTROL		
010424	1/4" SAE FLAT WASHER	2
010602	NUT, HEX 1/4"-20 A FINISHED ZP	1
010617	1/4" X 3/4" HEX HEAD BOLT	2
012408	#10-24 HEX KEP LOCKNUT	4
012570	#6-32 X 1" RD HD MACHINE SCREW - SLOTTED	2
012731	#6-32 MACHINE NUT	2
012732	#6 LOCKWASHER	2
012793	1/4-20 NYLOCK NUT	4
412381	14/3 BLACK SJTOW WIRE	8
451017	HANGER BRACKET, 67 DEG	1
470614	4" X 3" VAL-CO DECAL	1
690159	SCREW, 1/4-20 X 2-1/4 HHTB ZP	1
720015	SWITCH SHIELD	1
720018	DIAPHRAM - 7" X 6.5"	1
720020	HANGER BRACKET, 90 DEG	1
720023	MOUNTING BRACKET	1
720092	BODY ASSY, ADJ SWITCH	1
720093	BRACKET, TENSIONER	1
720094	ELECTRIC BOX, ADJ SWITCH	1
720095	SWITCH PLATE, ADJ SWITCH	1
720096	COVER, TENSIONER	1
720098	SPRING, .028 X .437 X .75	1
720099	DECAL, SENSITIVITY ADJUSTMENT	1
720100	STRAIN RELIEF, 90 DEG FOR 14/3	1
730047	HIGH VOLTAGE WARNING LABEL	1
730058	#16-14 RING TERMINAL	1
730516	SCREW, 10-32 X 1/4 PPH TRS ZP	8
730521	TERMINAL, SPADE, 16-14AWG, #6 BLUE	2
730989	MICRO SWITCH, SPDT 20A, 250VAC SCREW TERMINAL	1

Anti-Roost Insulator Bracket Assembly (451042)




PART #	DESCRIPTION	QTY
451042 ANTI-ROOST INSULATOR BRACKET ASSEMBLY		
010253	3/8" SPLIT LOCK WASHER	1
010669	3/8" X 2" HEX BOLT	1
011115	3/8-16 HEX NUT	1
450015	INSULATOR BRACKET	1
450419	WIRE PULLEY INSULATOR	1
451040	FEEDER TUBE CLAMP	1
451041	ANTI-ROOST INSULATOR BRACKET	1
VC353	CLAMP, 1/16 CABLE, WIRE ROPE CLIP	2

Feed Tubes - Smooth Tube Parts List



PART #	DESCRIPTION
FEED TUBES - SMOOTH TUBES	
450224	9' TUBE - 1 HOLE
450081	9' TUBE - 2 HOLES
451033	9' TUBE - 3 HOLES
450145	9' TUBE - 4 HOLES
455076	9' TUBE - 4 HOLES + 4 CENTERED BEST START HOLES
451047	10' TUBE - 0 HOLES
450082	10' TUBE - 2 HOLES
450083	10' TUBE - 3 HOLES
450084	10' TUBE - 4 HOLES
450072	10' TUBE - 3 HOLES + 3 CENTERED BEST START HOLES
451032	10' TUBE - 4 HOLES + 2 CENTERED BEST START HOLES
450099	10' TUBE - 4 HOLES + 4 CENTERED BEST START HOLES
450945	12' TUBE - 4 HOLES
450085	12' TUBE - 5 HOLES
450064	12' TUBE - 5 HOLES + 5 CENTERED BEST START HOLES
FEED TUBES - CONTROL SMOOTH TUBES	
455267	9' TUBE - 1 HOLE
455269	9' TUBE - 2 HOLES
455271	9' TUBE - 3 HOLES
455202	9' TUBE - 4 HOLES
455273	9' TUBE - 4 HOLES + 4 CENTERED BEST START HOLES
455275	10' TUBE - 2 HOLES
455277	10' TUBE - 3 HOLES
455205	10' TUBE - 4 HOLES
455279	10' TUBE - 3 HOLES + 3 CENTERED BEST START HOLES
455281	10' TUBE - 4 HOLES + 2 CENTERED BEST START HOLES
455283	10' TUBE - 4 HOLES + 4 CENTERED BEST START HOLES
455285	12' TUBE - 4 HOLES
455287	12' TUBE - 5 HOLES
455289	12' TUBE - 5 HOLES + 5 CENTERED BEST START HOLES

Feed Tubes - Ribbed Tube Parts List



PART #	DESCRIPTION
FEED TUBES - RIBBED TUBES	
455626	9' TUBE - 3 HOLES
450920	9' TUBE - 4 HOLES
455627	9' TUBE - 3 HOLES + 3 CENTERED BEST START HOLES
451031	9' TUBE - 4 HOLES + 2 CENTERED BEST START HOLES
450921	9' TUBE - 4 HOLES + 4 CENTERED BEST START HOLES
451000	10' TUBE - 0 HOLES
450908	10' TUBE - 2 HOLES
450909	10' TUBE - 3 HOLES
450910	10' TUBE - 4 HOLES
450911	10' TUBE - 3 HOLES + 3 CENTERED BEST START HOLES
455625	10' TUBE - 4 HOLES + 2 CENTERED BEST START HOLES
450913	10' TUBE - 4 HOLES + 4 CENTERED BEST START HOLES
451005	12' TUBE - 3 HOLES
450924	12' TUBE - 4 HOLES
450925	12' TUBE - 5 HOLES
450926	12' TUBE - 4 HOLES + 4 CENTERED BEST START HOLES
450928	12' TUBE - 5 HOLES + 5 CENTERED BEST START HOLES
FEED TUBES - CONTROL RIBBED TUBES	
455628	9' TUBE - 3 HOLES
455219	9' TUBE - 4 HOLES
455629	9' TUBE - 3 HOLES + 3 CENTERED BEST START HOLES
455630	9' TUBE - 4 HOLES + 2 CENTERED BEST START HOLES
455223	10' TUBE - 4 HOLES
455624	10' TUBE - 4 HOLES + 2 CENTERED BEST START HOLES
455248	10' TUBE - 4 HOLES + 4 CENTERED BEST START HOLES

Auger - Parts List



PART #	DESCRIPTION
AUGER	
450450-205	205' ROLL - 1.438" O.D. AUGER
450450-225	225' ROLL - 1.438" O.D. AUGER
450450-245	245' ROLL - 1.438" O.D. AUGER
450450-265	265' ROLL - 1.438" O.D. AUGER
450450-285	285' ROLL - 1.438" O.D. AUGER
450450-305	305' ROLL - 1.438" O.D. AUGER
450450-325	325' ROLL - 1.438" O.D. AUGER
450450-345	345' ROLL - 1.438" O.D. AUGER
450450-365	365' ROLL - 1.438" O.D. AUGER
450450-385	385' ROLL - 1.438" O.D. AUGER
450450-405	405' ROLL - 1.438" O.D. AUGER
450450-425	425' ROLL - 1.438" O.D. AUGER
450450-445	445' ROLL - 1.438" O.D. AUGER
450450-465	465' ROLL - 1.438" O.D. AUGER
450450-485	485' ROLL - 1.438" O.D. AUGER
450450-505	505' ROLL - 1.438" O.D. AUGER